

## Cyclone Separator

Cyclones are used for removal of particles with diameter more than a few microns from gases. Gas enters from the side and acquires a rotational speed. Particles are moved towards the wall due to centrifugal forces.

Radial force balance for a particle in

$\frac{d^2r}{dt^2}$  is small and may be neglected. Neglecting also  $v_r^f$ , it follows that

$$v_r^p = \frac{dr}{dt} = \frac{mr}{3\pi\mu d} \left(\frac{d\theta}{dt}\right)^2 \quad (2)$$

or

$$\frac{dr}{d\theta} = \frac{m}{3\pi\mu d} \left(r \frac{d\theta}{dt}\right) = \frac{mv_\theta^p}{3\pi\mu d}, \quad (3)$$

where  $\frac{dr}{dt} = \frac{dr}{d\theta} \frac{d\theta}{dt}$  is used.

It is assumed that

$$v_\theta^p \approx v_\theta^f. \quad (4)$$

Equation (3) then becomes

$$\frac{3\pi\mu d}{m} \frac{dr}{v_\theta^f} = d\theta, \quad (5)$$

or

$$\theta = \frac{3\pi\mu d}{m} \int \frac{dr}{v_\theta^f}. \quad (6)$$




Figure 1. Schematic diagram of a cyclone.

The number of turns needed to deposit the particles of size  $d$  (that is, moving the particles from the radius  $a$  to the side wall at  $r=b$ ) is given by

$$N_t = \frac{\theta}{2\pi} = \frac{3\mu d}{2m} \int_a^b \frac{dr}{v_\theta^f}, \quad (7)$$

or

$$N_t = \frac{9\mu}{\pi d^2 \rho^p} \int_a^b \frac{dr}{v_\theta^f}. \quad (8)$$

Alternatively, the smallest particle that can be removed in  $N_t$  turns is given by

$$d_{\min} = \left[ \frac{9\mu}{\pi \rho^p N_t} \int_a^b \frac{dr}{v_\theta^f} \right]^{1/2}. \quad (9)$$

In practice, an approximate expression

$$d_{\min} \sim \left[ \frac{\mu(b-a)}{\rho^p N_t U} \right]^{1/2}, \quad (10)$$

is used, where  $U$  is the mean inlet velocity.